



Eco 2 Wall Hanger Instruction

Parts List

Images are for illustrations only



Wall Side (1 Pc)




TV Part
(2 Pcs)



Rawl Plug
(2 Pcs)



Bush
(2 Pcs)



SHDW
6X40
(2 Pcs)



M5X30
(2 Pcs)



W14X6.5X1
(2 Pcs)

For all models



M4X12
(4 Pcs)




W16x4.5x1
(4 Pcs)

EF32



M4x10
(4 Pcs)



W16x4.5x1
(4 Pcs)

32S3EG
32S3REG




M6x24
W14x6.5x1
(2 Pcs both)



M6x10 / M6x12
W14x6.5x1
(2 Pcs both)

43C9MG



M6x10 / M6x12
W14x6.5x1
(4 Pcs both)




32C7 Series
43R/RS
43S2FG/JFG
43D210
43S3EG
43S6DG

VESA 200 X 200

Maximum Size of Mounting Hole

VESA 200 X 100 (for 43RS/43R)

Maximum Size of Mounting Hole



30 mm

Distance from Wall



8 KG

Maximum Safe Load

